




siegmund® workstation



164200

164205

164210

164215

Online



Bernd Siegmund GmbH
Ährenstraße 29
86845 Großaitingen
Tel. 0049 (0) 8203 / 96 07-0
Fax 0049 (0) 8203 /96 07-33
info@siegmund.com
www.siegmund.com

The screenshot shows the Siegmund website interface. At the top, there is a navigation bar with the Siegmund logo and several menu items: System 28, System 22, System 16, Positioner, Rail System, and Platform System. Below the navigation bar, there is a search bar and a 'GO' button. The main content area is titled 'Assembly instructions / User manual' and features a 3D rendering of a black metal worktable with a grey top and blue perforated shelves. A red 'Attention!' warning is displayed below the table, stating: 'This video does not replace the written installation instructions / user manual. Please read them before mounting / usage.' Below the table, there is a video player interface with a play button and a progress bar. At the bottom of the page, there is a footer with contact information and a printer icon.

siegmund
Welding Tables and Clamping Systems

System 28 Welding Tables | System 22 Welding Tables | System 16 Welding Tables | Positioner Manipulators | Rail System Rail System | Platform System Platform System

Company Profile | Catalog | Contact | Download | News | Login |

Assembly instructions / User manual

Attention!
This video does not replace the written installation instructions / user manual. Please read them before mounting / usage.

MENU | Siegmund Workstation 1/3 |

This video applies for the following items:

© Bernd Siegmund GmbH · Ährenstraße 29 · 86845 Grossaitingen · Telefon: +49 (0) 82 03 / 96 07-0 · Fax: +49 (0) 82 03 / 96 07-33 · E-Mail: info@siegmund.com · www.siegmund.com
Imprint | Privacy Policy | GTC

Siegmund Workstation

Montageanleitung · Assembly instructions · Инструкция за монтаж · Instrução de montagem · Montážní instrukce · Montagevejledning · Instrucciones de montaje · Asennusohjeet · Instructions d'assemblage · Upute za montažu · Szerelési útmutató · Istruzioni per montaggio · Montagehandleiding · Monteringsanvisning · Instrukcja montażu · Instruções de montagem · Instructiuni de montaj · Uputstvo za montažu · Инструкция по сборке · Monteringsanvisningar · Navodilo za sestavljanje · Návod na montáž · Montaj talimatları · 安装指南 · 組み立て方法








DE	Handfest - Bitte nicht festziehen.
BG	Ръчно завинтване - моля, не затягайте с помощен инструмент.
CZ	Ručně zašroubováno - prosím nedotahujte.
DK	Håndskruet - stram venligst ikke.
EE	Käsitsi kinnitav - ärge kinnitage jõuga.
EN	Hand-screwed - please do not tighten.
ES	Enroscado a mano - no apretar
FI	Käsikäyttö - ei saa kiristää työkalulla.
FR	Serré à la main - Ne pas serrer.
GR	Βιδώστε με το χέρι - παρακαλούμε μην σφίγγετε.
HR	Ručno zategnuti - ne prejako.
HU	Kézi rögzítés - ne húzza meg erősen.
IT	Avvitare a mano - non serrare forte.
LT	Rankinis prisukamas - prašome neužveržkite.
NL	Aandraaien met de hand - niet te vast aandraaien.
NO	Hånd skrudd, ikke stram til.
PL	Przykręcić ręcznie - proszę nie dokręcać.
PT	Aperto manual - por favor não force o aperto.
RO	Înșurubat manual - vă rugăm să nu strângeți.
RS	Ručno zavrnuti - molimo vas da ne pretežete.
RU	Завинчивать вручную - не затягивать.
SE	Handskruvad - spänn inte åt.
SI	Ročno priviti - prosim ne zategujte.
SK	Ručné naskrutkovanie - prosím, neufahujte silou.
TR	El vidalı - lütfen sıkmayın.





DE	Mit Schraubenschlüssel festziehen.
BG	Затегнете с гаечен ключ.
CZ	Utáhněte pomocí klíče.
DK	Stram med nøgle.
EE	Pingutatav võtmeaga.
EN	Tighten by wrench.
ES	Apretado con llave.
FI	Kiristä jakoavaimella.
FR	Serrer avec une clé.
GR	Σφίξιμο με κλειδί.
HR	Zategnuti ključem.
HU	Kulccsal feszítse meg.
IT	Serrare con chiave.
LT	Priveržkite veržliarakčiu.
NL	Aandraaien met een sleutel.
NO	Stram til med fastnøkkel.
PL	Przykręcić kluczem.
PT	Aperto com chave.
RO	Strângeți cu o cheie.
RS	Zategnuti ključem.
RU	Затянуть ключом.
SE	Spänn åt med skiftnyckel.
SI	Priviti s ključem.
SK	Utiahnite kľúčom.
TR	Anahtarla sıkmak.






Tools:






Screws:


<p>a</p>  <p>M6</p> <p>21x</p>	<p>g</p>  <p>M4</p> <p>6x</p>	
<p>c</p>  <p>M6x12 - ISO 7380</p> <p>4x</p>	<p>j</p>  <p>M6x12 - ISO 7380</p> <p>5x</p>	
<p>h</p>  <p>M4x10 ISO 7046-1</p> <p>6x</p>	<p>i</p>  <p>M6x16 ISO 7046-1</p> <p>12x</p>	



Parts:


R  1x	S  1x	T  1x
U  1x	V  1x	W  1x
X  2x	Y  2x	




60 mm - 164200


R	T	X	Y	a	g	c / j	h	i
								
1x	1x	2x	2x	19x	6x	7x	6x	12x




120 mm - 164205






S	U	X	Y	a	g	c / j	h	i
								
1x	1x	2x	2x	21x	6x	9x	6x	12x


180 mm - 164210

S	V	X	Y	a	g	c / j	h	i
								
1x	1x	2x	2x	21x	6x	9x	6x	12x


240 mm - 164215

S	W	X	Y	a	g	c / j	h	i
								
1x	1x	2x	2x	21x	6x	9x	6x	12x





60 mm


120 mm

180 mm

240 mm






6.1.1




X	Y	a	i
1x	2x	4x	4x


Tools




Y2
 6.1.4



Y1
 6.1.2




6.1.1




Y3	a	i
1x	M6	M6x16
1x	2x	2x









Tools

-
-




2x








6.1.2




Y1	a	i
	M6	M6x16
1x	4x	4x

Tools





6.1.3



X	Y	a	i
2x	2x	8x M6	8x M6x16


Tools

-
-




→ Y2

6.1.4








6.1.3



Y3	a	i
2x	M6 4x	M6x16 4x

Tools

-
-




6.1.4

R	T 60 mm	Y2
1x	1x	2x

a	g	c / j	h
M6	M4	M6x12	M4x10
7x	6x	4x / 3x	6x

Tools	





6.1.4



S	U 120 mm	V 180 mm	W 240 mm	Y2
1x	1x	1x	1x	2x

a	g	c / j	h
M6	M4	M6x12	M4x10
9x	6x	4x / 5x	6x





Tools



6.1.5



6.1.5



Bernd Sigmund GmbH

Ährenstraße 29 | 86845 Großaitingen | Deutschland (Bayern) | Telefon 0049 (0) 82 03 / 96 07 - 0 | Fax 0049 (0) 82 03 / 96 07 - 33
info@sigmund.com | www.sigmund.com

Alle Preise verstehen sich zzgl. gesetzl. MwSt., Verpackungs- und Transportkosten. Technische Änderungen vorbehalten.
Es gelten unsere allgemeinen Geschäftsbedingungen. Preisänderungen und Druckfehler vorbehalten.

Alle Texte, Bilder und Gestaltungselemente unterliegen dem Copyright der Bernd Sigmund GmbH. Kein Teil dieses Flyers darf ohne schriftliche Genehmigung des Rechtsinhabers analog, digital oder in einer anderen Form bearbeitet, vervielfältigt oder außerhalb dieser Broschüre veröffentlicht werden.